

ASSEMBLY INSTRUCTION**KIT PORTATARGA
KAWASAKI VERSYS '19****KV6104-19****WWW.BARRACUDAMOTO.COM****KIT**

- | | |
|---|---|
| <p>1/2. LICENSE PLATE KIT HOLDER
KIT PORTATARGA
KIT DE MATRICULA
KENNZEICHENHALTER KIT
KIT DE PLAQUE D'IMMATRICULATION</p> <p>3. SCREW M6X16
VITE M6X16
TORNILLO M6X16
SCHRAUBE M6X16
VIS M6X16</p> | <p>4. LARGE WASHER Ø6
RONDELLA LARGA Ø6
ARANDELA ANCHA Ø6
BREITE SCHEIBE Ø6
LARGE LAVEUSE Ø6</p> <p>5. SELF-BLOCKING NUT
DADO AUTOBLOCCANTE
AUTO TUERCA DE BLOQUEO
SELBSTVERRIEGELUNG MUTTER
ÉCROU AUTO-BLOQUANT</p> <p>6. ORIGINAL M6 SCREW
VITE M6 ORIGINALE
TORNILLO ORIGINALES M6
ORIGINALEN SCHRAUBE M6
VIS D'ORIGINE M6</p> |
|---|---|

PROCEDURA DI MONTAGGIO:

1. RIMUOVERE IL PORTATARGA ORIGINALE.
2. POSIZIONARE LA BULLONERIA, IN CORRISPONDENZA DEI FORI NEL VANO SOTTOSELLA SERVENDOSI DELLE BRUGOLE M6X16 (3) IN DOTAZIONE E DELLE M6 ORIGINALI DELLA MOTO (6).
3. SERRARE IL TUTTO.



EN: WE RECOMMEND AN INCLINATION NOT MORE THAN 30° TO AVOID PENALTIES AND POSSIBLE STRUCTURAL DAMAGES.

IT: CONSIGLIAMO UN'INCLINAZIONE NON SUPER OLTRE I 30° PER EVITARE SANZIONI E POSSIBILI DANNI STRUTTURALI.

ES: RECOMENDAMOS UNA INCLINACIÓN DE NO MÁS DE 30° PARA EVITAR SANCIONES Y POSIBLES DAÑOS ESTRUCTURALES.

DE: WIR EMPFEHLEN EINE STEIGUNG VON NICHT MEHR ALS 30°, UM STRAFEN UND MÖGLICHE STRUKTURELLE SCHÄDEN ZU VERMEIDEN.

FR: NOUS VOUS RECOMMANDONS DE NE PAS INCLINER À PLUS DE 30° POUR ÉVITER LES PÉNALTÉS ET LES DOMMAGES STRUCTUREL POSSIBLES.

