

## ASSEMBLING INSTRUCTION

### EXTRALIGHT BRACKET

**HF9003-21**

## LEGEND

1. EXTRALIGHT BRACKET  
STAFFA FARETTO  
SOPORTES DE FARO  
SCHEINWERFERHALTER  
FIXATIONS PHARE
2. ALLEN SCREW M6X10  
VITE A BRUGOLA M6X10  
TORNILLO ALLEN M6X10  
INBUSSCHRAUBE M6X10  
VIS ALLEN M6X10

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

